

**Product List**

from 01/May/2011

**CISS for the Epson inkjet printers :**

Item	Printer Model		Colors	CISS Flying		CISS Mbox	
				Empty	W/Ink	Empty	W/Ink
Europe and Africa	Epson Stylus S22/SX125 Epson Stylus SX420W/425W Epson Stylus BX305F/BX305FWe...	T1281-T1284 ***	4 Colors				
	Epson Stylus SX425W/SX420W/SX525WD/SX620FW Epson Stylus BX625FWD/BX305F/BX305FW/BX320FW/BX525WD ...	T1291-T1294 ***	4 Colors				
	Epson Stylus BX525WD /BX625FWD/BX320FW Epson Stylus SX525WD/SX620FW	T1301-T1304 ***	4 Colors				
North America	EPSON Workforce 320/323/325/520 EPSON Stylus NX125/NX127/NX420 EPSON Stylus NX625...	T1251-T1254 ***	4 Colors				
	EPSON Workforce 520/630/633/635/840...	T1261-T1264 ***	4 Colors				
	EPSON Workforce 630/633/635/840 EPSON Stylus NX625	T1271-T1274 ***	4 Colors				
Pan Pacific, Aisa, Ocean	Epson Stylus T12/T22, N11/NX125, TX120/TX129/TX420W/TX320F, Workfoce 325...	T1331-T1334 ***	4 Colors				
	Epson Stylus NX420, Workfoce 320/325/633/625W...	T1381-T1384 ***	4 Colors				
	Epson Stylus Workfoce 625/630/633...	T1401-T1404 ***	4 Colors				
	DX7000F, DX7400, DX7450,DX8400, DX8450, DX9400 ,DX9400F, BX300F, BX600FW, BX610FW, SX200,SX205, SX215, SX400, SX405, SX415, SX515W, SX600FW, SX610FW , D78, D92, DX4000, DX4400, DX4450, DX5000 , DX5050 , DX6000 , DX6050, or more...	T0711-T0714 ***	4 Colors				

Europe and Africa	P50, PX650, PX700W, PX710W, PX720WD, PX800FW, PX810FW, PX820FWD, R265, R285, E R360, RX560, RX585, RX685, or more...	T0801-T0806 (compatible T0791-796) **	6 Colors				
	D120, BX310FN,	T0711+T0711-T0714 (2x black cartridges) **	5 Colors				
	B1100	T0711H+T0711H-T002-004(2x black cartridges)	5 Colors				
	Photo 1400	T0791-T0796	6 Colors				
Asia, Oceania, South America	T30, T40W, TX300F, TX600FW, TX610FW, T20, T21, TX100, TX110, TX200, TX210, TX400, TX410, TX550W, C110, C79, C90, CX3900, CX4900, CX5500, CX5900, CX6900F, CX7300, CX8300, CX9300F, or more...	T0731N-T0734N (compatible T0731-734) ***	4 Colors				
	T50, TX650, TX700W, TX710W, TX800FW, TX810FW, R270, R290, R390, RX590, RX610, RX690, or more...	T0821N-T0826N (compatible T0821-826, T0811-816) **	6 Colors				
	C110, TX510FN,	T0731N+T0731N-T0734N (2x black cartridges) **	5 Colors				
	T1100	T0731HN+0731HN+1032-1034 (2x black cartridges)	5 Colors				
	Photo 1410	T0811-T0816	6 Colors				
South America	EPSON T26 /EPSON TX106 /EPSON TX109	T0921-T0924	4 Colors				
	NX100/NX105/NX200/NX300/NX400, WorkForce 30, CX4400/ CX4450/ CX7400/ CX7450/ CX8400/ CX9400fax	T0881-T0884	4 Colors				
North America	WorkForce 315, WorkForce 500, WorkForce 600, WorkForce 610, WorkForce 615, WorkForce 40, CX5000, CX6000, CX7000F, CX7400, CX7450, CX8400, CX9400Fax, CX9475Fax, NX100, NX105, NX110, NX115, NX215, NX300, NX400, NX415, NX510, NX515, or more...	T0691-T0694 (compatible T0681-684) ***	4 Colors				
	Artisan 50, R260, R280, R380, RX580, RX595, RX680, or more...	T0781-T0786 (compactible T0771-776) **	6 Colors				
	Artisan 600, 700, 800, 710, 835	T0991-T0996 (compactible T0981-986) **	6 Colors				
	C120, WorkForce 30, WorkForce 310, WorkForce 1100	T0691+T0691-T0694 (2x black cartridges) **	5 Colors				
	Photo 1400	T0791-T0796	6 Colors				
Worldwide	R1900	T0870-T0879	8 Colors				

5/36 O'Riordan Street, Alexandria, NSW 2015, Australia

<http://www.mir-aus.com>

Worldwide	R2880	T0961-T0969	9 Colors				
-----------	-------	-------------	----------	--	--	--	--

**Older Epson`s models**

	R200/ R220/ R300/ R300M/ R320/ R340/ RX500/ RX600/ RX620 / RX640	T0481-T0486	6 Colors				
	R210/ R230/ R310/ R350/ RX510/ RX630/ RX650	T0491-T0496					
	R800/ R1800	T0540-T0549	8 Colors				

**Large format ink cartridge (For Epson printers):**

	4000/ 4400/ 4800/ 600/ , 4880	refillable ( use a chip resetter),220ml	ABS Material	10.3/pcs , transparent and high quality
	7400/ 9400, 7800/ 9800, 7880/ 9880	refillable ( use a chip resetter),220ml		10.8/pcs , transparent and high quality

**CISS for the Canon inkjet printers :**

Item	Printer Model	Cartridge Model	Colors	CISS Flying		CISS Mbox	
				Empty	W/Ink	Empty	W/Ink
America	Canon PIXMA Photo inkjet printer , PIXMA MG5120 , PIXMA MG5220 , PIXMA MG6120 , PIXMA MG8120 , PIXMA iP4820 ,PIXMA MG6120 ( with CLI-226 Gray ), PIXMA MG8120 ( with CLI-226 Gray )	PGI-225BK, CLI-226C/ CLI-226M/ CLI-2216/ CLI-226BK ***	5 Colors , WITHOUT chips. Use original chips #				
	PIXMA Photo inkjet printer , PIXMA iP3600, PIXMA iP4600, PIXMA iP4700, PIXMA MP560, PIXMA MP620, PIXMA MP620B, PIXMA MP640, PIXMA MP640R,	PGI-220BK, CLI-221C/ CLI-221M/ CLI-221Y/ CLI-221BK ***	5 Colors , WITH compatible auto-reset chips				
	PIXMA MP980, PIXMA MP990	PGI-220BK, CLI-221C/ CLI-221M/ CLI-221Y/ CLI-221BK / CLI-221GY *	6 Colors , WITH compatible auto-reset chips				
Europe, Oceania	PIXMA Photo inkjet printer , PIXMA MG5150 , PIXMA MG5250 , PIXMA MG6150 , PIXMA MG8150 , PIXMA iP4850 ,PIXMA MG6150 ( with CLI-526 Gray ), PIXMA MG8150 ( with CLI-526 Gray )	PGI-525BK, CLI-526C/ CLI-526M/ CLI-526Y/ CLI-526BK ***	5 Colors , WITHOUT chips. Use original chips #				
	PIXMA Photo inkjet printer , PIXMA iP3600, PIXMA iP4600, PIXMA iP4700, PIXMA MP560, PIXMA MP620, PIXMA MP620B, PIXMA MP640, PIXMA MP640R, PIXMA MX860, PIXMA MX870	PGI-520BK, CLI-521C/ CLI-521M/ CLI-521Y/ CLI-521BK ***	5 Colors , WITH compatible auto-reset chips				
	PIXMA MP980, PIXMA MP990	PGI-520BK, CLI-521C/ CLI-521M/ CLI-521Y/ CLI-521BK / CLI-521GY *	6 Colors , WITH compatible auto-reset chips				
	PIXMA Photo inkjet printer , PIXMA MG5180 , PIXMA MG5280 , PIXMA MG6180 , PIXMA MG8180 , PIXMA iP4880 ,PIXMA MG6180 ( with CLI-826 Gray ), PIXMA MG8180 ( with CLI-826 Gray )	PGI-825BK, CLI-826C/ CLI-826M/ CLI-826Y/ CLI-826BK ***	5 Colors , WITHOUT chips. Use original chips #				

Asia	PIXMA iP3680, PIXMA iP4680, PIXMA iP4700, PIXMA MP560, PIXMA MP620, PIXMA MP620B, PIXMA MP640, PIXMA MP640R, PIXMA MX860, PIXMA MX870	PGI-820BK, CLI-821C/ CLI-821M/ CLI-821Y/ CLI-821BK ***	5 Colors , WITH compatible auto-reset chips				
	PIXMA MP980, PIXMA MP990	PGI-820BK, CLI-821C/ CLI-821M/ CLI-821Y/ CLI-821BK / CLI-821GY *	6 Colors , WITH compatible auto-reset chips				
Worldwide	IP4200/ 4300/ 4500/ 5200/ 5200R/ 5300, MP500/ MP530/ MP600/ MP610/ MP800/ MP800R/ MP810/ MP830/ MP950	PGI-5BK, CLI-8C/ CLI-8M/ CLI-8Y/ CLI-8BK *	WITH compatible auto-reset chips				
	IX4000/IX5000/IP3300/3500	PGI-5BK, CLI-8C/ CLI-8M/ CLI-8Y	WITH compatible auto-reset chips				
	S800/ S900/ S820/ S820D/ S830D/ i905D/ i950/ i9100/ PIXMA Ip6000D	BCI-6BK/6C/6M/6Y/6PM/6PC	6 Colors #				
	IP6700	CLI-8BK/C/M/Y/PC/PM					
	MP 970	CLI-8C/8M/8Y/8PC/8PM/PGI-5BK	7 Colors #				
	i9950/ i9900/ PIXMA ip8500	BCI-6BK/6C/6M/6Y/6PM/6PC/6R/6G	8 Colors #				
	Pro 9000	CLI-8 G/R/PM/BK/PC/C/M/Y					

Notice: for most models of Canon printers , the original chips of cartridges can be used on our cartridges.

**CISS for the HP(Hewlett Packard) inkjet printers :**

Item	Printer Model	Cartridge Model	Colors	CISS Flying		CISS Mbox	
				Empty	W/Ink	Empty	W/Ink
	HP Officejet 6000 Printer, HP Officejet 6500 All-in-One Printer, HP Officejet 7000 Wide Format Printer	920 C / 920XL C 920 M / 920XL M 920 Y / 920XL Y 920 K / 920XL K **	4 Colors, WITHOUT chips. Use original chips #				
	HP Officejet Pro 8000 Printer, HP Officejet Pro 8500 All-in-One Printer, HP Officejet Pro 8500A e-All-in-One Printer	940 C / 940XL C 940 M / 940XL M 940 Y / 940XL Y 940 K / 940XL K **	4 Colors, WITHOUT chips. Use original chips #				
	HP Photosmart D5445 Printer, HP Photosmart D5460 Printer, HP Photosmart C6340 All-in-One Printer, HP Photosmart C6350 All-in-One Printer, HP Photosmart C6380 All-in-One Printer, HP Photosmart D7560 Printer, HP Photosmart Premium Fax e-All-in-One Printer - C410a, HP Photosmart B8550 Photo Printer	364 C / 364XL C 346 M / 364XL M 364 Y / 364XL Y 364 K / 364XL K *	5 Colors, WITHOUT chips. Use original chips #				

5/36 O'Riordan Street, Alexandria, NSW 2015, Australia

<http://www.mir-aus.com>

America	HP Photosmart D5445 Printer, HP Photosmart D5460 Printer, HP Photosmart C6340 All-in-One Printer, HP Photosmart C6350 All-in-One Printer, HP Photosmart C6380 All-in-One Printer, HP Photosmart D7560 Printer, HP Photosmart Premium Fax e-All-in-One Printer - C410a, HP Photosmart B8550 Photo Printer	364 C / 364XL C 346 M / 364XL M 364 Y / 364XL Y 364 K / 364XL K 364 K / 364XL K (North America) *	5 Colors, WITHOUT chips. Use original chips #				
	Design Jet 70/ 100/ 110series Business inkJet1000/ 1200/ 2000/ 2200/ 2250/ 2230/ 2280/ 2300/ 2600/ 2800/ 1300/ cp1700, OfficeJet 850/ 850dn/ 9100/ 9110/ 9120/ 9130	HP10(69ml) C4844A , HP11(28ml) C4836A/37A/38A	4 Colors, WITH compatible auto-reset chips				
	OfficeK550/ K550 dtn/ K5400/ L7580/ L7680/ L7780/ L7500/ L7600/ L7700	(HP88) C9396A/ C9391A/ C9392A/ C9393A					
Europe	3210/3310/8250/C5180/C6180/C6270/C6280/C6825/ C7180/C7280/C8180/C6160/D7160/D7360/D7460	(363) 8721/8771/8772/8773/8774/8775	6 Colors,, WITH compatible auto-reset chips				
Japan	3213/ 3313/ 8200/ 3210	(177) 8721/8771/8772/8773/8774/8775					
America	3110/ 3310/ C5150/ D6160/ D7355/ 3210/ 3310xi/ C5180/ D7145/ D7360/ 3210v/ 8230/ C6100/ C6150/ D7155/ D7460/ 3210xi/ 8250/ C6180/ D7160/ 3300/ C5140/ C7180/ D7345/ C5100/ C7280/ C8100/ C6280/ D7100/ C8180/ C7250/ D7460/ D7260/ D7163/ D7363	(02) 8721/8771/8772/8773/8774/8775					

Notice: for most models of HP printers , the original chips of cartridges can be used on our cartridges.

**CISS for the Brother inkjet printers :**

Item	Printer Model	Cartridge Model	Colors	CISS Flying		CISS Mbox	
				Empty	W/Ink	Empty	W/Ink
Europe	Brother DCP-J125 / J315W / J515W / MFC-J265W / J410 / J415W / J220	LC39 / LC985 BK LC39 / LC985 C LC39 / LC985 M LC39 / LC985 Y **	4 Colors				
America	Brother MFC-795CW / DCP-185C / MFC-250C / MFC-490CW / DCP-385C / DCP-6690CW / MFC- 790CW / MFC-5490CN / MFC-5890CN / MFC- 6490CW / MFC-6890CDW / DCP-145C / DCP-165C / MFC-290C / DCP-585CW	LC61 / LC990 BK LC61 / LC990 C LC61 / LC990 M LC61 / LC990 Y (LC38/ LC67 / LC970/ LC1100) **	4 Colors				
Asia	Brother FAX-1360 / MFC-3360C / DCP155C / DCP350C / DCP560CN / MFC230C / MFC265C / MFC465CN / MFC685CW / DCP540CN / MFC440CN / DCP130C / MFC665CW / FAX2480 / MFC5460 / MFC240C / DCP330C / MFC-5460CN /	LC51 / LC960 BK LC51 / LC960 C LC51 / LC960 M LC51 / LC960 Y (LC37/ LC57 / LC1000) **	4 Colors				
	Brother MFC-210C/ 420CN/ 620CN/ 3240C/ 3340CN/ 5440CN/ 5840CN IntelliFAX-1840C/ 1940CN/ 2440C/ C215C/ C310CN/ 3340CN/ 410CN/ 425CN/ 5480CN/ 640CW/ 820CW; DCP-110C/ 310CN/ FAX-1835C/ DCP115C/ DCP117C/ DCP120C/ DCP310CN/ DCP315CN/ DCP340CW; FAX 1840C/ FAX 1940CN/ FAX 2440C	LC 09/ 900/ 950/ 41/ 47 ( old models)	4 Colors				