



**Tel: 02 80655614**  
**1300 213 589**  
**[www.mir-aus.com.au](http://www.mir-aus.com.au)**  
**[info@mir-aus.com](mailto:info@mir-aus.com)**

## **INSTALLATION INSTRUCTIONS FOR ALL HP 932/933 - 950/951 REFILLABLE CARTRIDGES**



## INSTALLATION INSTRUCTIONS FOR ALL HP 932/933 - 950/951 REFILLABLE CARTRIDGES

This model of refillable cartridges includes auto reset chips and prime tool. You just need to fill the cartridges, prime them and print! the whole operation is very easy.

### How to refill the Hp inkjet Printer cartridges:

Each cartridge has two holes,  
First N1 for ink and second N2 for air. (pic1)

1) Open 2 holes on the top part of cartridge.  
(pic 2)


2) Get ink in syringe and put a needle  
On a syringe.


3) Put a needle in filling hole N1.  
Do not damage inside walls of cartridges

4) Fill enough quantity of ink in refill  
cartridge (pic 3).


5) Close filling hole N1 with a plug, a hole  
N2 please leave cap open.

6) Fill other cartridges, use separate  
Syringe for each colour.





When you are done with refilling you need to prime all of the cartridges with Prime tool as shown in the pictures.



**Working Position of holes: N1 closed and N2 open.**

Put set of refill cartridges in the printer. Wait until all operations are done by MFU and please wait until it is ready to work. At first installation of refilled cartridges printer will show 100% level of inks. During printing level of inks will get lower. When printer shows the message that inks has ended, press the button "continue printing" in dialog box.

After that, printer will continue printing without displaying of the ink levels. Therefore it is necessary to visually control the rest of inks in a cartridges through its transparent walls.



## Questions and answers

### ***Printer does not recognize cartridges***

- make sure that all chips are properly placed on their places on a cartridge and there is no ink and dirt on them. Do not touch chips with your hands.
- make sure the cartridges are installed properly and click into the printer.
- install all set of refill cartridges.
- cartridge hole in the working position: N1 - closed, N2 - open.
- Install cartridges one by one and controlling on display what cartridge does not work.

### ***Ink does not come to printing head:***

- make sure that cartridges are filled properly and air holes are open
- cartridge hole in the working position: N1 - closed, N2 - open.

## Safety Guides

1. Keep out of reach of children. Seek medical advice if taken.
2. Avoid exposure to direct sunshine and don't keep it at high or Freezing temperatures.
3. Avoid Knocks and bumps.
4. Please avoid taking out the cartridges after installing the CIS ink system Ehere possible.
5. This product is designed to operate within 10-40 degrees Celsius.
6. The refillable cartridges has passed strict compatibility check, so we suggest Using our ink and cartridges to maintain printer quality.
7. Mixing two different brands of ink into the refillable cartridges is not recommended.
8. Please do not mix this refillable cartridges with original one or any other brand.

### **YOU ARE NOW READY TO PRINT WITH MIR-AUS REFILLABLE CARTRIDGES!**

**For more information and technical support please contact us at any time.  
02-80655614 / 1300-213-589**